
Battery for Irobot, 7150, Roomba 5150, Roomba 7550 14.4V, 3400mAh - 48.96Wh

Product price:

C\$70.00

Product short description:

Product Information

Fits Brands:- Irobot

Fits Models:- 7150, I31502f, I8550, Roomba 5150, Roomba 7550, Roomba E5, Roomba E5150, Roomba E515020, Roomba E5152, Roomba E5154, Roomba E5158, Roomba E515840, Roomba E6, Roomba E6 E6134, Roomba E6198, Roomba E619820, Roomba I3, Roomba I4, Roomba I7, Roomba I7+, Roomba I7158, Roomba I7550, Roomba I755020, Roomba I7558, Roomba I8, Roomba I8+, Roomba J7

Fits Battery Model Numbers:- 4624864, Abl-d1, Abl-d2
Specifications

- Item No.: CS-IRB710VX
- Type: Li-ion
- Capacity: 3400mAh / 48.96Wh
- Voltage: 14.4V
- Colour: Black
- Dimension: 74.20 x 51.00 x 50.20mm
- EAN Code: 4894128153375
- Net Weight: 237.0g
- Gross Weight: 337.0g

We update this list as new information becomes available. See the product description for more details.

Remarks concerning this product:-

Product features:

Capacity.: 3400mAh

Dimensions (mm): 74.20 x 51.00 x 50.20mm

Chemistry.: Li-ion

Length (inches).: 5.48

Width (inches).: 2.02

Height (inches).: 1.99

Length (mm).: 139.16

Height (mm).: 50.5

Width (mm).: 51.38

Voltage.: 14.4V

Gross Weight.: 0.337 Kg

Colour.: Black

Ean Code: 4894128153375

Net Weight.: 0.237 Kg

Our Part Number: CS-IRB710VX

Special Remarks: Regarding "Error 23"

Special Remarks: When the APP is connected to Roomba i7, "error 23" should not appear when the battery is removed.

Special Remarks: When the APP is closed or disconnected from Roomba i7, "error 23" will appear when removing the battery and then installing the (CS or original) battery.

Special Remarks: To avoid the problem of the APP, customers are advised to ensure the APP is well connected to the machine.

Special Remarks: If "error 23" appears after installing the battery, please close the APP

Special Remarks: then remove the battery from the machine

Special Remarks: after that, press the start button of the machine for 10 seconds. And then, reinstall the battery and put it on the charger. Wait for the machine to start automatically. Finally, open the mobile APP to connect

Regarding "Error 23" When the APP is the machine.
connected to Roomba i7, "error 23" Watt Hour.: 48.96Wh
should not appear when the battery is Description: Canadian Batteries supplies high quality,
removed. When the APP is closed or Batteries For Irobot, 7150, Roomba 5150, Roomba 7550
disconnected from Roomba i7, "error 14.4v, 3400mah - 48.96wh
23" will appear when removing the Warranty Period: 30 Days to return for refund & 1 Year
battery and then installing the (CS or replacement warranty on this product.
original) battery. To avoid the problem
of the APP, customers are advised to
ensure the APP is well connected to the
machine. If "error 23" appears after
installing the battery, please close the
APP; then remove the battery from the
machine; after that, press the start
button of the machine for 10 seconds.
And then, reinstall the battery and put it
on the charger. Wait for the machine to
start automatically. Finally, open the
mobile APP to connect the machine.
Latest Update:- 12th December 2022

Product codes:

Reference: CS-IRB710VX

EAN13: 4894128153375

UPC: -

Product attributes:

Product gallery:

