

---

# Nikon En-el14, Mh-24 Camera Charger

Product price:

**C\$32.58**

## Product short description:

### Here's the latest fitment list

**Fits Brands:-** Nikon

**Fits Models:-** Coolpix P7000, Coolpix P7100, Coolpix P7700, Coolpix P7800, D3100, D3100 Dslr, D3200, D3200 Dslr, D3300, D5100, D5100 Dslr, D5200, D5300, D5500

**Fits Battery Model Numbers:-** En-el14, Mh-24

We update this list as new information becomes available, see the product description for more detailed information

Remarks with regards to this product:-

*Need us to confirm which battery you need - [CLICK HERE](#)*

*Latest Update:- 13th May 2022*

## Product features:

Length (inches):. 3.17

Width (inches):. 2.51

Height (inches):. 0.92

Length (mm):. 80.6

Height (mm):. 23.45

Width (mm):. 64

Voltage: 0V

Gross Weight: 0.1401 Kg

Colour: Black

Ean Code: 4894128114284

Net Weight: 40.1

Our Part Number: DF-ENEL14UH

Special Remarks: 0

Technical Tips: Do not order unless you have checked your model and battery number are shown

Will Replace these Manufacturers: Nikon

Actual Manufacturer: Cameron Sino Technology Limited

Alternative Models: CS-TOOLKITS

Warranty Period: 30 Days to return for refund & 1 Year replacement warranty on this product.

## Product codes:

Reference: DF-ENEL14UH

EAN13: 4894128114284

UPC: -

## Product attributes:

## Product gallery:

---

