
Battery for Pantech Reveal C790 Aladdin, C530, C530 SLATE 3.7V, 800mAh - 2.96Wh

Product price:

C\$27.34

Product short description:

Here's the latest fitment list

Fits Brands:- Pantech

Fits Models:- C530, C530 Slate, C790, Link, Link P7040, P7040, P7040p, Reveal C790, Reveal C790 Aladdin, Vega

Fits Battery Model Numbers:- 5htb0045b0a, Pbr-c530

We update this list as new information becomes available, see product description for more detailed information

Remarks with regards to this product:-

Need us to confirm which battery you need - [CLICK HERE](#)

Latest Update:- 1st December 2021

Product features:

Dimensions (mm): 44.05 x 39.27 x 5.51mm

Capacity.: 800mAh

Chemistry.: Li-ion

Length (inches).: 1.73

Width (inches).: 1.55

Height (inches).: 0.22

Length (mm).: 44.05

Height (mm).: 5.51

Width (mm).: 39.27

Voltage.: 3.7V

Gross Weight.: 0.045 Kg

Colour.: Black

Ean Code: 4894128048862

Net Weight.: 0.0195 Kg

Our Part Number: CS-PTC530SL

Watt Hour.: 2.96Wh

Description: Canadian Batteries supplies high quality, Batteries For Pantech Reveal C790 Aladdin, C530, C530 Slate 3.7v, 800mah - 2.96wh

Warranty Period: 30 Days to return for refund & 1 Year replacement warranty on this product.

Product codes:

Reference: CS-PTC530SL

EAN13: 4894128048862

UPC: -

Product attributes:

Product gallery:



TO USER
Model No. NP-FM50
Part No. 7591-1100
Version 1.0 © 2004 SONY
Lithium-Ion Rechargeable Pack

PRECAUTIONS ALWAYS WEAR YOUR SAFETY GOGGLES
1. DO NOT SHORT CIRCUIT THE BATTERY PACK TERMINALS.
2. DO NOT REVERSE POLARITY.
3. DO NOT DISPOSE OF THE BATTERY PACK INCORRECTLY.
4. DO NOT DISPOSE OF THE BATTERY PACK IN FIRE.
5. DO NOT DISPOSE OF THE BATTERY PACK IN WATER.
6. DO NOT DISPOSE OF THE BATTERY PACK IN A CONTAINER.
7. DO NOT DISPOSE OF THE BATTERY PACK IN A CONTAINER.
8. DO NOT DISPOSE OF THE BATTERY PACK IN A CONTAINER.
9. DO NOT DISPOSE OF THE BATTERY PACK IN A CONTAINER.

FOR INFO
1. CONTACT THE SONY SERVICE CENTER FOR THE NEAREST SERVICE CENTER.
2. CONTACT THE SONY SERVICE CENTER FOR THE NEAREST SERVICE CENTER.
3. CONTACT THE SONY SERVICE CENTER FOR THE NEAREST SERVICE CENTER.
4. CONTACT THE SONY SERVICE CENTER FOR THE NEAREST SERVICE CENTER.